# Nissan E51 Fitting

# Converter wiring




## E51 Identifying can bus Wiring

The can wires on vehicle are the twisted pair of Pink and Blue wires on the speedometer plug.
They are located in pins 4 &5 of the large white plug on the row of pins opposite the plug catch.

Cut wires one at a time approx 4 cm from plug and taking care not to let the wires short to anything

---

**Pink wire of vehicle = Can High**
**Blue wire of vehicle = Can Low**

***Loom side***

Connect the Yellow wire of converter to the cut Pink wire Loom side.
Connect the White wire of converter to the cut Blue wire Loom side.

***Clock side***

Connect the Green wire of converter to the cut Pink wire Clock / plug side.
Connect the Blue wire of converter to the cut Blue wire Clock / plug side.

Connect Red of converter to 12v and Black of converter to GND
If you need any help/advice please call 07951178250