# KBTV Speedo Converter / Delimiter

**MODEL:** **NISSAN Patrol 2001 +**

**LOCATION:** **SPEEDO HEAD**

**Remove the Speedo Head, then install the Speedo Converter as described below**

**1. Cut the SIGNAL wire**

**2.Connect the YELLOW wire from the Speedo Converter to the Signal wire from the Loom**

**3. Connect the GREEN wire from the Speedo Converter to the Signal wire on the Speedo Head Connector**

**4. Connect the RED wire to ANY 12V+**

**5. Connect the BLACK wire to ANY 0V- (Neg/Earth)**

**6. All connections should be soldered and insulated.**

**7. Insulate the unused GREY wire**

## VEHICLE COLOUR CODES & LOCATION

| | CONNECTOR | ROW | PIN | COLOUR |
|---|---|---|---|---|
| **SIGNAL WIRE** | BROWN 24 PIN | LEFT | 7 TOP | GREY |
| **12 V+** | BROWN 24 PIN | RIGHT | 2 TOP | WHITE/BLACK |
| **0V- GROUND** | BROWN 20 PIN | TOP | 1R | BLACK |
| **SIGNAL OUT** | BROWN 24 PIN | LEFT | 8 TOP | BLUE/YELLOW |

