KBTV Speedo Converter / Delimiter

MODEL: **NISSAN Patrol Pre 2001**

LOCATION: **SPEEDO HEAD**

Remove the Speedo Head, then install the Speedo Converter as described below

1. Cut the SIGNAL wire

2.Connect the YELLOW wire from the Speedo Converter to the Signal wire from the Loom

3. Connect the GREEN wire from the Speedo Converter to the Signal wire on the Speedo Head Connector

4. Connect the RED wire to ANY 12V+

5. Connect the BLACK wire to ANY 0V- (Neg/Earth)

6. All connections should be soldered and insulated.

7. Insulate the unused GREY wire

VEHICLE COLOUR CODES & LOCATION

	CONNECTOR	PIN	COLOUR
SIGNAL WIRE	12 PIN	3RD	LIGHT BLUE
12 V+	ANY 12V		
0V- GROUND	CHASSIS		

