KBTV Speedo Converter / Delimiter

MODEL: **TOYOTA Crown/Majestic**

LOCATION: **SPEEDO HEAD**

Remove the Speedo Head, then install the Speedo Converter as described below

1. Cut the SIGNAL wire

2.Connect the YELLOW wire from the Speedo Converter to the Signal wire from the Loom

3. Connect the GREY wire from the Speedo Converter to the Signal wire on the Speedo Head Connector

4.Cut the SIGNAL OUT WIRE diregard the connector end (speedo head) and connect the LOOM end to the YELLOW wire of the speedo converter (see diagram)

5. Connect the RED wire to the 12V+

6. Connect the BLACK wire to the 0V- (Neg/Earth)

7. All connections should be soldered and insulated.

8. insulate the unused GREEN wire

VEHICLE COLOUR CODES AND LOCATION

	CONNECTOR	PIN	COLOUR
SIGNAL WIRE	white	See picture	PINK
12v	white	See picture	Blue
GND			Use Chassis
SIGNAL OUT wire	White	See picture	Green

